



Kanalplan Kabel-TV

	Kanal	Frekvens	Kanalplats
	SVT 1	182,25 MHz	E06
	SVT 2	175,25 MHz	E05
	TV 3	252,25 MHz	S14
	TV 4	189,25 MHz	E07
	Kanal 5	231,25 MHz	S11
	TV 6	140,25 MHz	S06
	Sjuan	245,25 MHz	S13
	TV 8	210,25 MHz	E10
	Kanal 9	266,25 MHz	S16
	TV 10	203,25 MHz	E09
	TV 11	196,25 MHz	E08
	TV4 Film	287,25 MHz	S19
	Disney Channel	280,25 MHz	S18
	SVT24/Barnkanalen	154,25 MHz	S08
	BBC	238,25 MHz	S12
	Eurosport	273,25 MHz	S17
	TV 12	217,25 MHz	E11
	Discovery	224,25 MHz	E12
	TV4 Fakta	259,25 MHz	S15
	Kunskapskanalen	147,25 MHz	S07
	Lokal-TV	161,25 MHz	S09
	FM Radio		